

LENIS EASY ACCESS BATH

FITTING AND OPERATION INSTRUCTIONS

(Please read these instructions through carefully before commencing assembly).

NOTICE TO INSTALLER

- 1) **ALWAYS FIT A THERMOSTATICALLY CONTROLLED WATER FILLING SYSTEM ON THIS PRODUCT.**
- 2) Take care when handling and avoid knocks or damage.
- 3) Ensure the bath is adequately protected if you need to stand in it.
- 4) Do not place burning cigarettes in or on the bath
- 5) Do not allow paint strippers, spirits, dry cleaning agents, cleansers or bleaches to come into contact with the surface.
- 6) If a blow lamp is used, the flame must be kept well away from the product.
- 7) Use a silicon sealant to ensure a watertight joint between bath rim and wall.
- 8) When making joints to the waste fitting use only the washers provided and an approved sealing compound. **DO NOT** use boss white, linseed oil putty or similar oil based compounds. Avoid excessive force when tightening plastic nuts.

ASSEMBLY INSTRUCTIONS

Every care has been taken to ensure your bath arrives in perfect condition. Before installation, please remove protective packaging from the bath and inspect. The manufacturer will not accept responsibility for the installation of faulty or damaged products. We recommend the bath be recovered for protection during installation.

Your leg set will contain the following items:

- | | |
|---------------------------|------------------------------------|
| A) 2 off channel legs | B) 20 off 1/2" No.8 screws |
| C) 4 off adjustable feet | D) 8 off nuts to suit feet threads |
| E) 6 off L shape brackets | F) 6 off countersunk magnets |

- 1) Place bath legs across the base of the bath approx. 130-150mm from the ends of the encapsulated baseboard.
- 2) Fix in place using the 1/2" screws provided.
- 3) Apply one nut on each of the adjustable feet and secure each leg with the remaining nuts.

PRELIMINARY INSTALLATION

- 1) Ensure the floor is flat and level.
- 2) Position and level the bath, setting the height according to the bath panel supplied. Place two spirit levels across both ends of the bath to ensure both record the product being true, repeat either side of the door aperture. Failure to follow this practice can lead to door alignment/sealing problems.
- 3) Mark the feet and screw hole positions on the floor.
- 4) Scribe a line on the wall to the underside of the rim.

FINAL INSTALLATION

- 5) Remove the bath, and fit a softwood batten to the scribed line on the wall to act as additional support to the rim(s).
- 6) Apply a liberal amount of silicone sealant to the outer rim(s) of the bath, which will be adjacent to a wall. Reposition the bath ensuring that it is pushed firmly back to the wall(s) and that the feet are back in their original position.
- 7) Fill the bath with water just above door threshold to make sure the door is sealed.
- 8) Leave the bath until the silicone has completely cured, then complete the installation ensuring all fixings are secure.
- 9) Fit the L shaped brackets to the wooden blocks under the bath rim (4 for the front panel and 2 for the end panel).
- 10) Screw the countersunk magnets provided to the back of the bath panel, lining these up with the L shape brackets on the blocks so that they connect and provide a fixing for the bath panel.

Guarantee: This product carries a full 12 months manufacturers non-transferrable parts warranty.

Technical Assistance Help: Armour Plastics Limited, Pennywell Industrial Estate, Sunderland, Tyne & Wear, SR4 9EN
Tel: +44 (0)191 534 6061 **Fax:** +44 (0)191 534 3626 **Web:** www.renaissance-baths.co.uk