



**HTMSP19XX - Hot Water
Insulator Pipe**



**HTMSP5XX - Filter and Check
Valve Assembly**



HTMSP10XX - Battery Casing



HTMSP13XX - Sensor Cable



**HTMSP7XX - Hot Water
Blanking Assembly**



**HTMSP20XX - Check valve
assembly removal tool**



**HTMSP14XX - Filter and Seal
for Solenoid**



**HTMSP12XX - Tap Body
End Cap**



HTMSP2XX - Cartridge



**HTMSP21XX - 2 X Fibre
Washers**



**HTMSP22XX - Cartridge Stop
Rings**



**HTMFLUSH - Flushing
Connector**



HTMSP15XX - Cartridge Cover



HTMSP17XX - Sensor Complete



**HTMSP18XX - Brass Elbow
for Solenoid**



ID02500BAT - Batteries



ID02500AL6FL - Transformer



ID02812ELVK - Solenoid



HTMSP3XX - Inlet Leg (Cold)



HTMSP24XX - Base flange



HTMSP4XX - Inlet Leg (Hot)



**HTMSP16XX - Removable
Spout**

