


# Temperature & Mode Settings

The DIP switch is located on the front cover PCB.

### Default Settings



<b>Temperature</b>	<b>Switch 1</b>	<b>Switch 2</b>	<b>Range</b>
	OFF	OFF	30 - 41°C (BEAB Care)
	ON	OFF	30 - 43°C (Default Setting)
	OFF	ON	30 - 47°C
	ON	ON	30 - 41°C (BEAB Care)
<b>Pump Connection</b>	<b>Switch 3</b>	<b>Switch 4</b>	<b>Instruction</b>
	OFF	OFF	Wired pump on: switched / wireless pump off
	OFF	ON	Wired pump on: pulsed / wireless pump off
	ON	OFF	Wireless pump on / wired pump off
	ON	ON	Wireless pump on / wired pump off
<b>Bluetooth</b>	<b>Switch 5</b>		<b>Instruction</b>
	OFF		Bluetooth disabled
	ON		Bluetooth enabled
<b>Auto-Shutdown</b>	<b>Switch 6</b>	<b>Switch 7</b>	<b>Duration</b>
	OFF	OFF	30 Minutes
	ON	OFF	20 Minutes
	OFF	ON	10 Minutes
	ON	ON	5 Minutes

If BEAB Care (30 - 41°C Range) is selected, the shower will 'beep' once when the isolator is switched on.