Warranty Information

Proof of purchase will be required.

The guarantee does not cover faults or damage caused by incorrect installation and/or maintenance, ordinary wear and tear, water composition, etc.

*Please see www.methven.com for full terms and conditions of warranty.

Cleaning

Your product has a high-quality finish and should be treated with care to preserve the visible surfaces. Never use abrasives or abrasive cleaning agents to clean this product. Clean regularly with contamination free warm water and a damp soft cloth. Do not use products containing chlorine bleach or hydrochloric acid as these can damage the product.

We have a policy of continuous improvement and reserve the right to change specifications without notice.

METHVEN UK LIMITED
METHVEN EXPERIENCE CENTRE
3/3A STONE CROSS COURT
YEW TREE WAY
GOLBORNE
WARRINGTON
WA3 3JD
UNITED KINGDOM

INST-DUSMBK-V1 13.10.2020

TEL: 0800 195 1602

Dunston Flexi Sink Mixer

Installation Guide

Technical Specification Working Pressure:

Min: 0.3 Bar Max: 5.0 Bar

Operating Temperature:

Hot: 65°C Cold: 5°C

Inlet Connections:

1/2" BSP

Features:

- · On trend design perfectly complements contemporary kitchens
- Pull down nozzle is ideal for rinsing pots and pans
- Dual handles are fitted with ceramic discs for ease of operation
- · Optimised to operate at 6 litres per minute in order to save water
- · Chrome plated finish
- · In full colour packaging







Contents

Cleaning

Congratulations on your purchase of your new Methven Sink Mixer. Our fitting instructions have been created with you in mind to provide you with all the information you require and, if you need any further help, please don't hesitate to contact our customer care team on 0800 195 1602.

General Safety Information 3

Line Drawing 3

Product Breakdown 4

Product Breakdown 4

Installation Requirements 6

Installation 7

Warranty Information 8

8

Troubleshooting

Symptom	Cause(s)	Resolution	
Mixer not	Mains Water supply turned off	Turn on the mains water supply	
turning on	Closed isolation valve	Open isolation valve	
No hot water	Cold override	Check if the pressure is balanced. Fit	
		pressure equalising valve.	
Low Flow Rate/No Flow	Water supply failure	Investigate water supply, check plumbing	
		and heating system for any faults	
	Partially closed isolation valve	Open isolation valve	
	Air lock or partial blockage in the supply	Flush through pipework to ensure	
	pipework or hoses	removal of debris and any airlocks.	
	Water being drawn off elseware causing		
	pressure changes or instantaneous boiler	Try not to use other water outlets when	
	temperature changes. Ensure minimum	using the mixer	
	pressure is being met.		
Water dripping from the mixer	This is normal for a short time after using	This is due to residual water tension, the	
	the mixer	build up of water in the mixer spout.	
	If water continues to drip, possible issue	Please contact our customer care team.	
	with the flow control cartridge.		
Movement of fitted mixer	Fixing kit loose	Ensure fixing kit nut is sufficiently	
		tightened.	
	Extra support may be required depending	Please contact customer care to purchase	
	on the surface the tap is fitted to.	a under sink mounting triangle	

Installation Requirements


Before commencing installation of the new product, ensure that the system has been flushed to remove any debris, which could cause damage to the valves and invalidate the warranty.

Installation


- 1, Put the O-Ring (B) into the base ring
- 2, Pass both Flexi Tails (G) through the S.S fixing tub (A) into the tap body, ensuring that the O-Ring on the tail is positioned inside the tap body. Hand tighten, do not use PTFE tape or similar to create the seal.
- 3, Offer the tap up to the hole in the sink
- 4, On the underside of the sink fit the Triangle fixing board (C) rubber gasket (D) and S.S gasket (E) on to the s.s. fixing tub (A)


Note: Plastic Triangle Fixing Board - This should be used on thin work surfaces to help distribute the weight of the tap and provide a thicker mounting surface for the fixing kit to clamp to.

- 5, Install the plastic fixing nut (F) and fasten on to the s.s. Fixing tub (A) by hand
- 6, Connect the male end of the tail to the corresponding hot and cold inlets.
- 7, Reinstate water supply and test for leaks.



Do not stretch or twist hose







Please keep these instructions for future reference and request of replacement parts

General Safety Information

Please read all of the instructions before installation.


Methven recommends this product is installed by a competent person in compliance with all relevant regional regulations.


Remove all packaging and check the components for damage before starting installation.

This product must not be modified in any way as this will invalidate the guarantee.

It is the responsibility of the installer to ensure a waterproof seal is achieved, after installation all connections must be checked for leaks.


All outlets used primarily for personal hygiene shall deliver water at a safe temperature as per regional regulations.





Product Breakdown

 ${\it Check\ All\ components\ are\ present\ prior\ to\ starting\ installation.}$



Part No	Description
1	Indicator
2	Screw
3	Handle - Hot Water
4	Anti-wear Ring
5	Headwork - Hot Water
6	Body
7	Headwork - Cold Water
8	Anti-wear Ring
9	Handle - Cold Water
10	O-Ring
11	Brass Outlet Tube
12	Plastic Gasket
13	Bracket
14	O-Ring
15	Brass Connector
16	Plastic Ring
17	Shower Hose
18	Spring Tube
19	Brass Connector
20	Check Valve
21	Aerator
22	Plastic Ring (on Bracket)

Part No	Description
23	Shower Body
24	Inside Part of Shower
25	Aerator
26	Base Ring
27	O-Ring
28	Fixing Tub
29	Plastic Board
30	Fixing Rubber Gasket
31	Fixing S.S Gasket
32	Fixing Nut
33	Flexible Hose

Shower Hose Parts			
Part No	Description		
1	O-Ring		
2	Brass Connector		
3	Nut		
4	Spare Part		
5	Inside Tub		
6	Nylon Yarn		
7	Brass Connector		
8	O-Ring		