



Opulence

Half Height Glass Shower Door Fitting Instructions


Corner Shower Door Options




BI-PARTING DOORS
Not handed illustrated



TWIN BI-FOLDING DOORS
Not handed illustrated



BI-FOLDING DOOR & A BI-PARTING DOOR
Left hand panel, right hand door illustrated




BI-FOLDING DOOR & A RETURN PANEL
Left hand panel, right hand door illustrated

Inline Shower Door Options



BI-PARTING DOORS
Not handed illustrated



BI-FOLDING DOOR & A FIXED PANEL
Left hand panel, right hand door illustrated



TWIN BI-FOLDING DOORS
Not handed illustrated



FIXED PANEL
Left hand panel illustrated



Read before installation:

PLEASE READ ALL INSTRUCTIONS CAREFULLY & LEAVE WITH THE END USER.

INSTRUCTIONS ARE PREPARED TO HELP WITH THE ASSEMBLY & INSTALLATION OF HALF HEIGHT SHOWER DOORS TO SUIT A CORNER OR INLINE / ALCOVE SETTING.

CAREFULLY UNPACK THE PRODUCT. ENSURE YOU DO NOT ACCIDENTALLY DISPOSE OF ANY PARTS.

CHECK THAT THE SHOWER AREA / SHOWER TRAY WHERE THE DOORS ARE TO BE INSTALLED IS LEVEL.

ALL SEALS ARE PRE-APPLIED AND SHOULD NOT BE REMOVED DURING INSTALLATION

PROTECT SHOWER TRAY SURFACES AND COVER ANY WASTES TO PREVENT LOSS OF SMALL ITEMS & TO PREVENT DEBRIS ENTERING THE PIPEWORK.

USE THE OUTER CARTON TO PROTECT THE FLOOR AND / OR WALL DURING ASSEMBLY IF NECESSARY.

ALLOW SUITABLE CURING TIME FOR SILICONE SEALANT. THIS COULD BE 24 HOURS DEPENDING UPON THE VARIETY USED.

IN THE CASE OF ANY DIFFICULTIES BEING ENCOUNTERED, PLEASE DO NOT HESITATE TO CONTACT OUR TECHNICAL DEPARTMENT ON **0845 402 9924**.

DUE TO THE NATURE OF ALL GLASS SHOWER DOORS, WE CANNOT GUARANTEE THEY ARE 100% WATERTIGHT.

WE DO NOT APPROVE THE USE OF POWER SHOWERS WITH EASY ACCESS SHOWER DOORS AND SHOWER TRAYS.



EASY CLEAN GLASS

Opulence glass shower enclosures are coated with an Easy Clean coating. The coating is an effective protection for easy to clean glass.

To optimize the durability of the Easy Clean protection, we recommend the following:

- Regularly rinse off the water & soap deposits by drying the surface with a squeegee or cloth if necessary.
- Clean the glass panels weekly (depending on the use & the hardness of the water).
- **Clean glass with warm soapy water or water containing a small amount of washing up liquid.** Rinse thoroughly & wipe with a soft, non-abrasive cloth.

DO NOT USE abrasive products, strong or concentrated acids, alkalis, chlorine or other abrasive cleaning products such as household bleach, disinfectant, bathroom limescale remover / mousse as they may discolour or damage the coating and void the warranty.




Technical Helpline: 0845 402 9924

Revision 1

from
CONTOUR
built-in independence

1: CHECK THE LEVEL!




Before you start the installation, **ENSURE** that the shower area / shower tray / wetfloor former area where the doors are to be fitted is level, both side to side and front to back, using a spirit level (indicated by the red dotted lines above).

2: COMPENSATOR STYLES



Place compensator against the wall ensuring that it rests on the flat area of the shower tray / wetfloor former.

3: POSITION COMPENSATOR



Mark position of wall compensator fixing points, checking the compensator is perfectly vertical. Drill holes with a suitable drill bit and insert suitable wall fixings. **(NOT SUPPLIED)**.


4: FIX COMPENSATOR



Run a bead of clear silicone bathroom sealant down the narrow face, for the full length of the outer compensator and then screw to the wall using suitable screws **(NOT SUPPLIED)**. Wipe **ANY** excess silicone from compensator/wall joint.

FOLLOW THE MANUFACTURERS GUIDELINES WHEN USING SILICONE SEALANT.

5: LOCATE PANEL "A"



Slide **"PANEL A"** into the wall compensator. An optional self adhesive protective strip is supplied for applying to the bottom edge of the glass panel, see inset above. We **recommend** using this on a tiled floor setting.

DO NOT DRILL FIXING HOLES INTO COMPENSATOR INNER YET.




DO NOT REMOVE PANEL STICKERS UNTIL DOORS ARE FULLY ASSEMBLED.

6: DOOR HINGE CLOSE UP



The hinge attached to **"PANEL A"** will have a spigot ready to accept **"PANEL B"**. Ensure the spigot part of the hinge is on the outer side of the door, with the receiving pin pointing upwards, to ensure the rise & fall hinges open outward.

7: LOCATE PANEL "B"




Offer **"PANEL B"** to **"PANEL A"**.

The female hinge section of **"PANEL B"** locates onto the male hinge section of **"PANEL A"**.

BI-PARTING DOOR OPTIONS DO NOT USE "PANEL B". GO TO STEP 9.

9: LOCATE PANEL "C"



REPEAT STEP 7

Connect **"PANEL C"** to **"PANEL B"** as described previously.

You have now assembled one section of your door.

Repeat STEPS 3 to 9 to complete the return panel or inline door panel assembly. DO NOT TIGHTEN ANY SCREWS YET.

11: THERE SHOULD BE NO GAPS!



With the doors assembled and in the closed position, **ENSURE** that the magnetic profiles where the door(s) / return panels meet at the corner are parallel and the magnetic profiles come together for the full height of the doors.

8: CONNECTING THE HINGE




Connect **"PANEL B"** to **"PANEL A"**

With a downward motion, connect **"PANEL B"** to **"PANEL A"**, gently pushing down until the top of the glass panels are level and the hinge is fully seated in the middle.


DO NOT TIGHTEN HINGE GRUBSCREWS YET.

10: PANELS MUST BE LEVEL!



Using a spirit level ensure the top of all the door panels are level, on both the long side and return side, and are also level where the magnetic profiles meet at the corner.

12: TIGHTEN ALL SCREWS




With the doors still in the closed position, use a 5mm allen key to fully tighten the 4 x allen screws on each hinge, *see above left*. Attach the 4 x chrome cover caps to cover the screw heads.


Using a 3mm allen key tighten the hinges top grub screw. This will secure each door panel in position, *see above right*.

You may find it easiest to do this whilst inside the shower area.

13: DRILL COMPENSATOR



Drill the **"PANEL A"** compensators with a 3mm drill bit through the pre-drilled 4.5mm hole on the compensator located on the inside face (inside of the shower area).



Using the screws supplied in **Pack "A"** securely fix both panels to the wall compensators and conceal using the supplied chrome cover caps.

15: FIX STABILISER BAR




Take the wall lug from the stabiliser bar and using suitable wall fixings (**NOT SUPPLIED**) screw securely to the wall, as shown above.

Re-attach the stabiliser bar to the wall lug & **"PANEL A"** as shown in Step 14.

REPEAT STEP FOR THE RETURN PANEL OR INLINE DOOR

17: SEAL WITH SILICONE



TIP: On the outside of the panel silicone along the compensator and the glass. On the inside silicone along the **glass only**.

Silicone joint between floor / shower tray both **"PANEL A's"**. Allow suitable cure time for silicone (this may be 24 hours depending on the variety used).

FOLLOW THE MANUFACTURERS GUIDELINES WHEN USING SILICONE SEALANT.

14: 45° STABILISER BAR



VIEW FROM INSIDE SHOWER AREA

Clip the stabiliser bar on to **"PANEL A"**

Mark the fixing point on the wall around the wall lug.

Unscrew the wall lug from the stabiliser bar with an allen key and use it to mark the centre point for the wall fixing. Drill a hole with a suitable drill bit and insert suitable wall fixings. (**NOT SUPPLIED**).

16: CUT TOP CAP TO SIZE




Measure from the wall to the front inside edge of **PANEL "A"** compensator, see above left. Using your measurement, measure from the front shoulder of the top cap back to the ribbed area of the top cap and mark, see above right.

Cut off the excess ribbed area with a small hacksaw.

The cut end of the cap should fit against the wall, see inset above.

OPTIONAL LATCH



Place the bracket of the latch against the leading edge of **PANEL "B"** (Next to **PANEL "C"**). Using a 4mm allen key tighten the grub screws, *do not overtighten*.

Contour Showers
Siddorn Street
Winsford
Cheshire CW7 2BA

contour
built-in independence