

UK Installation instructions Heat insulation pad for Sinks

1. Installation instructions

Thank you for your purchase of a Heat Insulation Pad for Shallow Bowl Kitchen Sinks - 500x500mm or 300x400mm

Please follow the installation instructions carefully:

1. Clean, degrease and dry the underside of your kitchen sink (If there is sound insulation present, the Heat Insulation Pad can be applied over the top of the sound insulation)
2. Create a template of the underside of your kitchen sink (make sure to include the waste)
3. Carefully cut around the template using a sharp pair of scissors or a suitable knife; then peel back the shiny protective waxed paper film, exposing the self-adhesive backing
4. Adhere the sink pad to the underside of the kitchen sink.

2. Technical Data

PROPERTIES	AVERAGE VALUE
ASTM D1056	2C2
Density	160 Kg m3
Compression Deflection 25% (35 – 63)	50 kpa
Shore Hardness "00" Scale	45-50
Elongation – Minimum	> 200%
Temperature Range (Constant)	-40 deg C / +80 deg C
Temperature Range (Intermittent)	+120 deg C
Water Absorption	< 5% vol
Tensile Strength	> 500 kpa
Flame Resistance	FMVSS302 UL 94 HF1
Environmental Protection	CFC & HCFC Free
Colour	Grey
<p>The above figures are average values and should be considered as guidelines and not specification. While reasonable care has been taken to ensure that this data is representative. Granberg UK does not warrant or otherwise guarantee, expressly or impliedly, the suitability, accuracy, reliability or completeness of the information</p>	